


PLINTH - INSTRUCTION MANUAL

Posted on 21-09-2026 by barpaadminuser




Instruction Manual Rack Plinth


- 1 Carefully lay the rack on its side on a protected surface and remove any levelling feet or casters fitted to the base.




- 2 Assemble the plinth frame by joining the front, rear and side panels with 8 M6x12 screws.




- 3 Align the plinth frame with the rack base and secure it using 4 M12x20 screws.



- 4 Return the rack to the upright position and adjust the plinth height until the rack is leveled and stable.



- 5 Tighten all fasteners. Ensure that the rack does not oscillate and that all corners are properly supported.



Final Check

- ✓ All eight M6x12 screws used to assemble the plinth frame are fitted and securely tightened.
- ✓ All four M12x20 screws securing the rack to the plinth are fitted and securely tightened.
- ✓ The rack is upright, level and stable, with no rocking.
- ✓ The plinth panels and adjustment mechanisms are properly secured.

